



THROTTLE CONTROL MODULE

PART NUMBER 20-1561

**SEE KNFILTERS.COM FOR CURRENT APPLICATIONS
AND CARB STATUS ON EACH PART FOR A SPECIFIC VEHICLE**



If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

NOTE: FAILURE TO FOLLOW INSTALLATION INSTRUCTIONS AND NOT USING THE PROVIDED HARDWARE MAY DAMAGE THE ENGINE.

WARNING: The battery cable MUST be disconnected before any components/electrical connections are disconnected. Failure to follow this step may result in DTC's being set and/or poor operation of this kit.

1. Turn off the ignition and disconnect the negative battery cable.



2. Release the locking tab and then disconnect the Throttle pedal electrical connection.



3. Connect the K&N® throttle wiring harness to the throttle pedal and connect the factory wiring harness to the K&N® wiring harness.



4. Find a suitable location to mount the sensitivity knob, drill a ¼" id hole, remove the knob and install the rheostat then reinstall the knob.

5. Find a suitable location to mount the K&N® Pedal Module and secure with tie wraps. Route the wiring harnesses to the pedal module and secure to the module. Secure the wiring harnesses with the provided tie wraps.

NOTE: Be sure the wiring harnesses and module will not be tangled in any pedal assemblies or steering components.

6. Reconnect the vehicle's negative battery cable. Double check to make sure everything is secure and properly positioned before starting the vehicle.

NOT LEGAL FOR SALE OR USE ON ANY POLLUTION CONTROLLED MOTOR VEHICLE IN CALIFORNIA OR STATES ADOPTING CALIFORNIA EMISSION PROCEDURES.

See knfilters.com for CARB status on each part for a specific vehicle